

EPSON PRINTER MOTHERBOARD L3110/L3150/L3210/L3250

Sale Price: 4000.0



PRODUCT ID: 0009416

Feature / Attribute	Specification Details
Component Name	Main Logic Board / Motherboard / PCA
Supported Printers	Epson EcoTank L3110, L3150, L3210, L3250
Connectivity Interface	• L3110 / L3210: High-Speed USB 2.0 Only • L3150 / L3250: High-Speed USB 2.0 + Wi-Fi & Wi-Fi Direct
Key Onboard Chips	Power Transistor Pair (typically A2222 & C6144), Head Driver IC, EEPROM
Core Responsibilities	• Translates incoming print jobs into physical execution paths • Manages wireless network protocols (L3150/L3250) • Distributes synchronized voltage pulses to the printhead nozzles • Processes feedback from paper, carriage, and ink tank sensors
Signs of Motherboard Failure	• No power at all (completely dead, no lights, no sound) • Powers on but instantly flashes all red lights (Fatal Error) • Machine runs and "prints" but outputs 100% blank pages • Computer displays "USB Device Not Recognized" or constant offline status